

Navilock Charger Plate for MAXI Charger C1037

Description

This charging plate by Navilock enables you to charge different rechargeable batteries and can be used together with the Navilock Maxi Charger (item 61700).



Item no. 65722

EAN: 4043619657223

Country of origin: China

Package: Blister

Specification

- Suitable for
 Casio: NP30
 FUJI: NP60, NP120, BT3, S301, 1037, 1137,
 DL-S5, DL-S6, DV-4, OD525
 Kodak: K5000, K5001
 Nikon: ENEL5, EL5
 Olympus: Li20B, VBA10, DL12, DB40
 Ricoh: DB40, DB43
 Samsung: 1037
 Toshiba: BT3
- Model: C1037
- Voltage: 4.2 V / 600 mA

System requirements

- Navilock 61700 Maxi Charger

Package content

- Charging plate

Images

