

MTK NMEA Packet User Manual

Revision: 0.3
Linked FW Version: 1.902_06
Release Date: 2006/05/02

MediaTek Inc.

MTK NMEA Packet Format

Preamble	TalkerID	PktType	DataField	*	CHK1	CHK2	CR	LF
----------	----------	---------	-----------	---	------	------	----	----

Packet Length:

The maximum length of each packet is restricted to **255** bytes

Packet Contents:

Preamble: One byte character.

'\$'

TalkderID: Four bytes character string.

"PMTK"

PktType: Three bytes character string.

From **"000"** to **"999"**

An identifier used to tell the decoder how to decode the packet

DataField: The DataField has variable length depending on the packet type.

A comma symbol **'.'** must be inserted ahead each data filed to help the decoder process the DataField. © 2007 Navilock Europe

Page 1/9

*****: 1 byte character. The star symbol is used to mark the end of DataField.

CHK1, CHK2: Two bytes character string.

CHK1 and CHK2 are the checksum of the data between Preamble and **'*'**.

CR, LF: Two bytes binary data.

The two bytes are used to identify the end of a packet.

Sample Packet:

\$PMTK000*32<CR><LF>

MTK NMEA Packet Protocol:

In order to inform the sender whether the receiver has received the packet, an acknowledge packet PMTK_ACK should return after the receiver receives a packet.

MTK NMEA Packet List:

Packet Type: 000 PMTK_TEST	3
Packet Type: 001 PMTK_ACK	3
Packet Type: 010 PMTK_SYS_MSG	3
Packet Type: 101 PMTK_CMD_HOT_START	3
Packet Type: 102 PMTK_CMD_WARM_START	3
Packet Type: 103 PMTK_CMD_COLD_START	3
Packet Type: 104 PMTK_CMD_FULL_COLD_START	3
Packet Type: 301 PMTK_API_SET_DGPS_MODE	4
Packet Type: 313 PMTK_API_SET_SBAS_ENABLED	4
Packet Type: 314 PMTK_API_SET_NMEA_OUTPUT	4
Packet Type: 320 PMTK_API_SET_PWR_SAV_MODE	4
Packet Type: 401 PMTK_API_Q_DGPS_MODE	4
Packet Type: 413 PMTK_API_Q_SBAS_ENABLED	4
Packet Type: 414 PMTK_API_Q_NMEA_OUTPUT	5
Packet Type: 420 PMTK_API_Q_PWR_SAV_MODE	6
Packet Type: 501 PMTK_DT_DGPS_MODE	6
Packet Type: 513 PMTK_DT_SBAS_ENABLED	7
Packet Type: 514 PMTK_DT_NMEA_OUTPUT	7
Packet Type: 520 PMTK_DT_PWR_SAV_MODE	7
Packet Type: 604 PMTK_Q_VERSION	7
Packet Type: 704 PMTK_DT_VERSION	7

Packet Type: 000 PMTK_TEST

Packet Meaning:

Test Packet.

DataField:

None

Example:

\$PMTK000*32<CR><LF>

Packet Type: 001 PMTK_ACK

Packet Meaning:

Acknowledge Packet

DataField:

PktType: The packet type the acknowledge responds.

Flag: '0' = Invalid packet.

'1' = Unsupported packet type

'2' = Valid packet, but action failed

'3' = Valid packet, and action succeeded

Example:

\$PMTK001,101,0*33<CR><LF>

Packet Type: 010 PMTK_SYS_MSG

Packet Meaning:

Output system message

DataField:

Msg: The system message.

'0': UNKNOWN

'1': STARTUP

:

Example:

\$PMTK010,001*2E<CR><LF>

Packet Type: 101 PMTK_CMD_HOT_START

Packet Meaning:

Hot Restart: Use all available data in the NV Store.

DataField:

None

Example:

\$PMTK101*32<CR><LF>

Packet Type: 102 PMTK_CMD_WARM_START

Packet Meaning:

Warm Restart: Don't use Ephemeris at re-start.

DataField:

None

Example:

\$PMTK102*31<CR><LF>

Packet Type: 103 PMTK_CMD_COLD_START

Packet Meaning:

Cold Restart: Don't use Time, Position, Almanacs and Ephemeris data at re-start.

DataField:

None

Example:

\$PMTK103*30<CR><LF>

Packet Type: 104 PMTK_CMD_FULL_COLD_START

Packet Meaning:

Full Cold Restart: It's essentially a Cold Restart, but additionally clear system/user configurations at re-start. That is, reset the receiver to the factory status.

DataField:

None

Example:

\$PMTK104*37<CR><LF>

Packet Type: 301 PMTK_API_SET_DGPS_MODE

Packet Meaning:

API_Set_Dgps_Mode

DGPS correction data source mode.

DataField:

PMTK301,Mode

Mode: DGPS data source mode.

`0': No DGPS source

`1': RTCM

`2': WAAS

Example:

```
$PMTK301,1*2D<CR><LF>
```

Packet Type: 313 PMTK_API_SET_SBAS_ENABLED

Packet Meaning:

API_Set_Sbas_Enabled

Enable to search a SBAS satellite or not.

DataField:

Enabled: Enable or disable

`0' = Disable

`1' = Enable

Example:

```
$PMTK313,1*2E<CR><LF>
```

Packet Type: 314 PMTK_API_SET_NMEA_OUTPUT

Packet Meaning:

API_Set_NMEA_Out

Set NMEA sentence output frequencies.

DataField:

There are totally 17 data fields that present output frequencies for the 17 supported NMEA sentences individually.

Supported NMEA Sentences

0 NMEA_SEN_GLL,	// GPGLL interval - Geographic Position - Latitude longitude
1 NMEA_SEN_RMC,	// GPRMC interval - Recommended Minimum Specific GNSS Sentence
2 NMEA_SEN_VTG,	// GPVTG interval - Course Over Ground and Ground Speed
3 NMEA_SEN_GGA,	// GPGGA interval - GPS Fix Data
4 NMEA_SEN_GSA,	// GPGSA interval - GNSS DOPS and Active Satellites
5 NMEA_SEN_GSV,	// GPGSV interval - GNSS Satellites in View
6 NMEA_SEN_GRS,	// GPGRS interval - GNSS Range Residuals
7 NMEA_SEN_GST,	// GPGST interval - GNSS Pseudorange Errors Statistics
13 NMEA_SEN_MALM,	// PMTKALM interval - GPS almanac information
14 NMEA_SEN_MEPH,	// PMTKEPH interval - GPS ephemeris information
15 NMEA_SEN_MDGP,	// PMTKDGP interval - GPS differential correction information
16 NMEA_SEN_MDBG,	// PMTKDBG interval - MTK debug information

Supported Frequency Setting

- 0 - Disabled or not supported sentence
- 1 - Output once every one position fix
- 2 - Output once every two position fixes
- 3 - Output once every three position fixes
- 4 - Output once every four position fixes
- 5 - Output once every five position fixes

Example:

```
$PMTK314,1,1,1,1,1,5,1,1,1,1,1,0,1,1,1,1*2C<CR><LF>
```

This command set GLL output frequency to be outputting once every 1 position fix, and RMC to be outputting once every 1 position fix, and so on.

You can also restore the system default setting via issue:

```
$PMTK314,-1*04<CR><LF>
```

Packet Type: 320 PMTK_API_SET_PWR_SAV_MODE

Packet Meaning:

API_Set_Pwr_Sav_Mode

Set power saving operation mode.

DataField:

PMTK320,Mode

Mode: 0: PWR_SAV_OFF: power saving mode off

1: PWR_SAV_ON: power saving mode on

Example:

```
$PMTK320,0*26<CR><LF>
```

Packet Type: 401 PMTK_API_Q_DGPS_MODE

Packet Meaning:

API_Query_Dgps_Mode

DataField:

None

Return:

PMTK_DT_DGPS_MODE

Example:

\$PMTK401*37<CR><LF>

Packet Type: 413 PMTK_API_Q_SBAS_ENABLED

Packet Meaning:

API_Query_Sbas_Enabled

DataField:

None

Return:

PMTK_DT_SBAS_ENABLED

Example:

\$PMTK413*34<CR><LF>

Packet Type: 414 PMTK_API_Q_NMEA_OUTPUT

Packet Meaning:

API_Query_NMEA_Out

Query current NMEA sentence output frequencies.

DataField:

None

Return:

PMTK_DT_NMEA_OUTPUT

Example:

\$PMTK414*33<CR><LF>

Packet Type: 420 PMTK_API_Q_PWR_SAV_MODE

Packet Meaning:

API_Query_Pwr_Sav_Mode

Query power saving operation mode.

DataField:

None

Return:

PMTK_DT_PWR_SAV_MODE

Example:

\$PMTK420*3F<CR><LF>

Packet Type: 501 PMTK_DT_DGPS_MODE

Packet Meaning:

© 2007 Navilock Europe

DGPS Data Source Mode

DataField:

Mode: DGPS data source mode

'0': No DGPS source

'1': RTCM

'2': WAAS

Example:

\$PMTK501,1*2B<CR><LF>

Packet Type: 513 PMTK_DT_SBAS_ENABLED

Packet Meaning:

Enable to search a SBAS satellite or not.

DataField:

Enabled: Enable or disable

'0' = Disable

'1' = Enable

Example:

\$PMTK513,1*28<CR><LF>

Packet Type: 514 PMTK_DT_NMEA_OUTPUT

Packet Meaning:

NMEA sentence output frequency setting

DataField:

There are totally 17 data fields that present output frequencies for the 17 supported NMEA sentences individually. Please refer to PMTK_API_SET_NMEA_OUTPUT for the Supported NMEA Sentences and Frequency Setting.

Example:

\$PMTK514,1,1,1,1,1,5,1,1,1,1,1,0,1,1,1*2A<CR><LF>

Packet Type: 520 PMTK_DT_PWR_SAV_MODE

Packet Meaning:

Power saving operation mode.

DataField:

PMTK520,Mode

Mode: 0: PWR_SAV_OFF: power saving mode off

1: PWR_SAV_ON: power saving mode on

Example:

\$PMTK520,0*24<CR><LF>

Packet Type: 604 PMTK_Q_VERSION

Packet Meaning:

Query the version information of FW

DataField:

NONE

Return:

PMTK_DT_VERSION

Example:

\$PMTK604*6D<CR><LF>

Packet Type: 704 PMTK_DT_VERSION

Packet Meaning:

Version information of FW.

DataField:

PMTK704,FWVrsn1, FWVrsn2, FWVrsn3

Vrsn: MainVersion_ReleaseNumber

Example:

\$PMTK704,1.881_06,0606_m0138,0000*52<CR><LF>